

Thank you for purchasing Quick Cap. As you know, the material is available in 1", 2", and 4" (nominal) spine thicknesses. The rolls have 6" cores and are 375' long. The adhesive is very tacky! Do not remove the backing until you're ready to apply it.

1) <u>Start with good edges.</u> When cutting your filters to size, often there will be excess "fuzz" left behind on the cardboard. Trim this with office/hand scissors. You don't need to cut the cardboard off, rather just trim off the excess "fuzz".

ProTip: Experience will let you know how much "fuzz" is acceptable to leave untrimmed.

2) <u>Cut Quick Cap to length.</u> Ensure that your cut is square. Gently fold material into a "U" before you peel off the backing. This will help open a "starting point" from which to start peeling.

ProTip: A razor blade can also help "start" the peeling if needed.

3) <u>Apply your Quick Cap material to the raw edge.</u> The adhesive used is "Pressure Sensitive", so you'll need to apply pressure to each contact point. Use your fingers or a needle nose.

ProTip: The needle nose listed in the picture have tips that are curved up--- (kiwi style) and help in making a good connection at hard-to-pinch cross member connections. Also, "dry stapling" (no staples loaded in the stapler) with a commercial hand or pneumatic stapler can be effective since it creates contact "dimples".

- 4) If the pleated filter material is lateral to the Quick Cap, pressing it with your fingertips up against the underside of the spine will create a great seal, *nearly eliminating air bypass!*
- 5) A small amount of tape at the corner, while not required, will also help reduce bypass by locking the Quick Cap into the corner.
- 6) Practice with Quick Cap and you're on your way to quickly and easily making professional looking and better performing cut-and-cap filters!

** IMPORTANT NOTE: Apply at Room Temperature (65+ degrees F)**











